





**46**  
 Kit etichette  
 Labels set  
 Jeu etiquette  
 Juego etiquetas  
 Etikettenkit

**19**  
 kit guarnizioni  
 Gasket set  
 Jeu joints  
 Juego juntas  
 Dichtungenkit










Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	50030285	Screw				
2	1	50040189R	Crankcase				
3	4	50030004R	Screw				
4	1	50030013R	Seal ring				
5	1	50030014R	Ring				
6	2	50030012R	Bearing				
7	1	50030011R	Crankshaft				
8	1	61070074	Seal ring				
9	2	50030010R	Spacer				
10	1	50030009R	Bearing				
11	2	50030008R	Ring				
12	1	50030007R	Piston pin				
13	1	50030006R	Piston ring				
14	1	50030002R	Cylinder				
15	1	50030388R	Gasket				
16	1	50030309	Muffler				
17	1	50030297R	Spark plug				
18	1	50032010	Piston assy Ø37				
19	1	50032008	Gasket set				
20	1	093500397	Starter handle				
21	1	4098073R	Starter rope				
22	1	004000132R	Spring				
23	1	094000033AR	Starter pulley				
24	2	004000436R	Pin				
25	2	50030112	Spring				
26	2	004000140R	Pawl				
27	1	50030143R	Flywheel				
28	1	005000361	Washer				
29	1	004000142	Nut				
30	1	50030272	Screw				
31	1	50030161	Flange				
32	2	50030295	Screw				
33	1	3833080	Washer				
34	1	094600097AR	Spark plug cap				
35	1	50030267R	Spring				
36	1	094500034R	Washer				
38	1	50030145	Spacer				
39	4	50030269R	Screw				
40	1	50032031R	Starter case				
41	1	094600041AR	Screw				
42	1	50030142R	Ignition coil				
43	1	50030160R	Bushing				
44	1	50030150	Sheath				
45	1	50030151R	Switch				
46	1	50032042	Labels kit				





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50030040R	Breather valve				
2	1	50030390	Bush				
3	1	50030286	Fittings				
4	2	50030037R	Band				
5	1	50030265R	Fuel line				
6	1	50030329R	Fittings				
7	1	50030036R	Fuel filter				
8	1	50032011	Chain tensioner screw				
9	1	50030125	Plate				
10	1	50030201	Cover				
11	1	50030270	Screw				
12	1	50030127R	Guard				
13	1	50030052	Clamp				
14	1	50030196AR	Crankcase				
15	2	50030269R	Screw				
16	1	50030207	Cover				
17	1	50030139R	Gasket				
18	3	50030291	Screw				
19	1	50032020R	Oil pump				
20	1	50030136R	Worm gear				
21	1	50030047	Oil line				
22	1	50030289	Filter				
23	1	50030046R	Bush				
24	1	50030173	Grommet				
25	1	50032057R	Oil suction				
26	8	50030272	Screw				
27	2	50030229R	Support				
28	1	50030053R	Breather valve				
29	2	50030085R	Support				
30	1	2318817R	Air purge				
31	1	50030385	Screw guide				
32	1	50160173	Fitting				
33	1	50030033	Breather valve				
34	4	50030374R	Screw				
35	1	50030268A	Gasket				
36	2	50030304AR	Cap				
37	1	50032012	Thrott.lever/ro				
38	1	50030057	Cover				
39	1	2318633R	Carburetor WT-705				
40	1	004000025	Gasket				
41	1	50030337	Starter lever				
42	2	50030284	Spacer				
43	1	50030022R	Valve				
44	2	50030276R	Screw				
45	1	50030308	Knob				
46	1	50030184R	Ring				
47	1	50030306R	Cover				
48	1	50030277R	Air filter				
49	1	50030281R	Filter				
50	1	50030023R	Gasket				
51	1	50030056R	Gasket				
52	1	50030177R	Grommet				
53	1	50030176R	Starter lever				
54	1	50030330R	Tube				
55	1	50030174	Screw guide				








Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50030269R	Screw				
2	2	50030279	Screw				
3	1	50030249R	Cover				
4	1	50030082A	Throttle lever				
5	1	50030077	Spring				
6	1	50030076R	Plug				
7	1	50030078R	Button				
8	1	50032037	Handle kit				
9	1	50030081	Plug				
10	1	50032012	Thrott.lever/ro				
11	1	50030080	Spring				
12	1	50030065R	Handle				
13	1	50030270	Screw				
14	1	50030068R	Strap				
15	1	50030067R	Support				
16	1	50030271	Screw				
17	1	50030138R	Clutch driver				
18	1	50030372	Bearing				
19	1	50032009	Clutch drum				
20	1	50030092	Washer				
21	1	50030350R	Spring				
22	1	50030090A	Clutch				
23	1	50032029AR	Chain cover				
24	1	50030242	Guard				
25	1	50030100	Spring				
26	1	3914003R	Nut				
27	1	3916005R	Washer				
28	1	50030105	Spacer				
29	1	50030292	Screw				
30	1	50030110	Spring				
31	1	50030106	Bushing				
32	1	50030107A	Weight				
33	1	50030205	Cover				
34	1	50030272	Screw				
35	1	50030116R	Plug				
36	1	50030118	Lever				
37	1	50030111	Spring				
38	1	50030117	Plug				
39	1	50030119	Brake band				
40	1	50030113	Brake lever				
41	1	50010148R	Nut				
42	1	50030121	Spring				
43	1	50032012	Thrott.lever/ro				


FINO A NOVEMBRE 2004  
 TILL NOVEMBER 2004  
 BIS NOVEMBER 2004  
 HASTA NOVIEMBRE 2004  
 JUSQU'A NOVEMBRE 2004

16 ■ KIT RIPARAZIONE  
 REPAIR KIT



DA NOVEMBRE 2004  
 FROM NOVEMBER 2004  
 AB NOVEMBER 2004  
 DESDE NOVIEMBRE 2004  
 DEPUIS NOVEMBRE 2004

16 ■ KIT RIPARAZIONE  
 REPAIR KIT





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318616	Spring				
2	2	2318617	Screw				
3	1	375100078	Shutter				
4	1	003300209	Screw				
5	1	2318615	Spring				
6	1	2318620	Shaft				
7	1	035000165	Spring				
8	1	2318618	Screw L				
9	1	2318619	Screw H				
10	1	093500115	Spring				
11	1	035000162	Screw				
12	1	2318191	Cover				
13	1	003300202	Screw				
14	1	003300201	Spindle				
15	1	093500218	Jet				
16	1	2318671	Repair kit				
17	1	2318614	Lever				
18	1	095000164	Ring				
19	1	003300036	Fittings				
20	1	2318612	Cover				
21	1	003300197	Screw				
23	1	50030361A	Carbuirettor kit WT-705				
25	1	094600142	Cap				
26	1	50030174	Screw guide				
27	1	50030175	Screw guide				
28	1	50030167R	Starter lever				
35	1	2318631	Adjust. screw				
36	2	2318867	Caps-lock				
37	1	50030385	Screw guide				
38	1	50030337	Starter lever				
51	1	2318633R	Carbuirettor WT-705				